CEROFFEE PRO Firmware Update

- Check your CEROFFEE's LCD version and keep it updated regularly.
- Check and download the latest firmware on CEROFFEE's website(www.ceroffee.com).
- How to check your LCD version:

  1) WiFi Number Check: Turn your CEROFFEE on and WiFi number will be shown on display for 2 seconds. Ex) E000022. E: English / C: Chinese.

  2) General Information and Version Check: Turn your CEROFFEE on and touch "CLEAR" then, the information will be shown on display.

  - WiFi O(X): O - Connected, X - Disconnected

  - M 800(1600): Model name – 800: CRF800 | 1600: CRF1600

  - W 1450(2600): Maximum heater output – 1450 Watt: CRF800 | 2600 Watt: CRF1600

  - 220V 10: 220V - Rated voltage(it varies depending on country)


    10 - Voltage deviation(± 10%)

  - D 26 M 13: Firmware version – D26: LCD version / M13: Mainboard version

CEROFFEE

- How to update

1. Download the latest firmware from CEROFFEE homepage.
2. Decompress and save it to USB.
3. Turn off CEROFFEE and push the switch on the bottom of LCD to the left.



4. Plug USB into LCD.

   * DO NOT plug in when the switch is on.

5. Turn on CEROFFEE and update begins: UPDATE -> DONE.






6. Turn off CEROFFEE.

7. Remove USB.

8. Push the switch on the bottom of LCD to the right.



9. Turn on CEROFFEE.

10. LCD shows PRGM-01.

11. Touch “CLEAR” button and check the version.

